



Immobiliser System (w/ Entry & Start System) (Korea),  
Entry & Start System (Korea), Starting (w/ Entry & Start System) (Korea), Steering Lock  
(w/ Entry & Start System) (Korea) and Wireless Door Lock Control (w/ Entry & Start System) (Korea)



Immobiliser System (w/ Entry & Start System) (Korea),  
Entry & Start System (Korea), Starting (w/ Entry & Start System) (Korea), Steering Lock  
(w/ Entry & Start System) (Korea) and Wireless Door Lock Control (w/ Entry & Start System) (Korea)

TOYOTA RAV4 (EM3090E)



Immobiliser System (w/ Entry & Start System) (Korea),  
Entry & Start System (Korea), Starting (w/ Entry & Start System) (Korea), Steering Lock  
(w/ Entry & Start System) (Korea) and Wireless Door Lock Control (w/ Entry & Start System) (Korea)


13

14

15

16

G82(A), G83(B), G84(C)  
Certification ECU



53 TOYOTA RAV4 (Cont' d)

Immobiliser System (w/ Entry & Start System) (Korea),  
Entry & Start System (Korea), Starting (w/ Entry & Start System) (Korea), Steering Lock  
(w/ Entry & Start System) (Korea) and Wireless Door Lock Control (w/ Entry & Start System) (Korea)

