

Headlight (Korea)

Automatic Light Control (Korea),
Light Auto Turn Off System (Korea)
and Light Reminder (Korea)

Front Fog Light (Korea)

5


6


7

8

G78(A), G79(B)
Main Body ECU

TOYOTA RAV4 (EM3090E)





Illumination (Korea)



21

22


23


24

Illumination (Korea)

G78(A), G79(B)
Main Body ECU

G103
No. 16 Junction Connector






Wiring diagram for G78(A), G79(B) Main Body ECU. The diagram shows the ECU connected to various components including Map Light Assembly (Q12, Q11), No. 1 Room Light Assembly (Q8), and Vanity Light Switch LH (Q4), Vanity Light Assembly LH (Q3), and Vanity Light Switch RH (Q1), Vanity Light Assembly RH (Q2). The ECU is connected to a power source (W) and ground (W-B). The diagram includes a legend for wire colors: W (White), GR (Green), and W-B (White-Black).

Legend:

- *18 : w/ Sliding Roof
- *19 : w/o Sliding Roof


*18 : w/ Sliding Roof
*19 : w/o Sliding Roof

Door Lock Control (Korea)



Door Lock Control (Korea)

*26 : w/ Power Seat



TOYOTA RAV4 (EM3090E)

Door Lock Control (Korea)

