



SEQUOIA (EM08L0U)

Engine Control (3UR-FE)




SEQUOIA (EM08L0U)




Engine Control (3UR-FE)

+ 1 : Shielded




Engine Control (3UR-FE)

\* 1 : Shielded





Cruise Control or Dynamic Radar Cruise Control (3UR-FE)

\* 2 : w/ Dynamic Radar Cruise Control



\* 2 : w/ Dynamic Radar Cruise Control





## SEQUOIA (EM08L0U)

