



Engine Control (2UZ-FE)




SEQUOIA (EM08L0U)

## Engine Control (2UZ-FE)




Engine Control (2UZ-FE)

\* 1 : Shielded



Engine Control (2UZ-FE)


\* 1 : Shielded




\* 2 : w/ Dynamic Radar Cruise Control



\* 2 : w/ Dynamic Radar Cruise Control



Electronically Controlled Transmission and A/T Indicator (2UZ-FE)



8 SEQUOIA (Cont' d)

Electronically Controlled Transmission and A/T Indicator (2UZ-FE)

- \* 2 : w/ Dynamic Radar Cruise Control
- \* 4 : Optitron Meter
- \* 5 : Except Optitron Meter

