

# F RELAY LOCATIONS

## [Engine Room R/B and Engine Room J/B Inner Circuit]

\* 1:Except 130A Type Generator Assembly  
 \* 2:130A Type Generator Assembly



