

F RELAY LOCATIONS

 : J/B No.6	Instrument Panel Right (See Page 20)
--	--------------------------------------

