

- A 1 Front Airbag Sensor RH
- A 2 Front Airbag Sensor LH
- A 3 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Sub-Assembly)
- A 8 High Pitched Horn Assembly
- A 9 Low Pitched Horn Assembly
- A 10 Headlight Assembly LH
- A 11 Headlight Assembly RH
- A 12 Headlight Assembly LH
- A 13 Headlight Assembly RH
- A 15 Turn Signal Light and Parking Light LH (Headlight Assembly LH)
- A 16 Turn Signal Light and Parking Light RH (Headlight Assembly RH)
- A 18 Ambient Temperature Sensor (No.1 Cooler Thermistor)
- A 19 ABS and Traction Actuator Assembly
- A 20 Brake Booster Assembly
- A 21 Brake Booster Assembly
- A 22 A/C Pressure Sensor
- A 23 Windshield Wiper Motor Assembly
- A 24 Windshield Washer Motor and Pump Assembly
- A 25 Front Wiper Deicer (Windshield Glass)
- A 26 Laser Radar Sensor
- A 27 ECM
- A 30 Headlight Cleaner Motor and Pump Assembly
- A 31 Level Warning Switch Assembly
- A 32 Headlight Cleaner Control Relay
- A 33 Security Horn Assembly
- A 34 Cooling Fan Motor
- A 35 Security Courtesy Switch
- A 36 Fog Light Assembly LH
- A 37 Fog Light Assembly RH
- A 38 Side Marker Light RH (Headlight Assembly RH)
- A 39 Side Marker Light LH (Headlight Assembly LH)
- A 40 Wireless Door Lock Buzzer
- A 42 Rear Washer Motor and Pump Assembly
- A 54 Junction Connector
- A 61 Junction Connector

# Position of Parts in Engine Compartment <2UZ-FE>

A 1  
Yellow




A 2  
Yellow




A 3  
Gray




A 8  
Black




A 9  
Black




A 10  
Black




A 11  
Black



A 12  
Black



A 13  
Black



A 15  
Gray




A 16  
Gray




A 18  
Black




A 19  
Black



A 20  
Black



A 21  
Black




A 22  
Black




A 23  
Black



A 24  
Black



A 25  
Black



A 26  
Black



# Position of Parts in Engine Compartment <2UZ-FE>

