
















Position of Parts in Instrument Panel




H	1	Main Body ECU
H	2	Main Body ECU
H	3	Main Body ECU
H	4	Main Body ECU
H	5	Skid Control Buzzer Assembly
H	6	Steering Sensor
H	7	No.1 Stereo Jack Adapter Assembly
H	9	Back Door Power Window Regulator Switch Assembly
H	10	Ignition or Starter Switch Assembly
H	11	Headlight Dimmer Switch Assembly
H	13	Spiral Cable Sub-Assembly
H	14	Windshield Wiper Switch Assembly
H	15	Windshield Wiper Switch Assembly
H	16	Front Room Temperature Sensor (Cooler Thermistor)
H	17	Cigarette Lighter Assembly
H	19	DLC3
H	21	Un-Lock Warning Switch Assembly
H	24	A/C Amplifier Assembly
H	27	Transponder Key Amplifier
H	28	Key Inter Lock Solenoid
H	29	VSC Off Switch
H	30	Pattern Select Switch Assembly
H	31	Transmission Control Switch
H	32	Transponder Key ECU Assembly
H	35	Shift Lock Control ECU Sub-Assembly
H	37	Combination Meter Assembly
H	38	Power Steering ECU Assembly
H	39	Turn Signal Flasher Assembly
H	40	Tire Pressure Warning ECU
H	41	Front Blower with Fan Motor Sub-Assembly
H	42	Glove Box Light Assembly
H	43	Clearance Warning ECU Assembly
H	44	Towing Brake Controller
H	45	Integration Control and Panel Assembly
H	46	Curtain Airbag Cutoff Switch
H	47	Front Seat Heater Switch LH
H	48	Front Seat Heater Switch RH
H	49	Front Seat Heater Switch RH
H	50	Main Switch Assembly
H	51	Front Power Point Socket Assembly
H	52	Tire Pressure Warning Reset Switch
H	53	Power Source Control ECU
H	54	Spiral Cable Sub-Assembly
H	55	Back Up Light Relay
H	56	Center Airbag Sensor Assembly

Position of Parts in Instrument Panel




Position of Parts in Instrument Panel

H 24
White




H 27
Black




H 28
Black




H 29
Black




H 30
Black




H 31
Black




H 32
White




H 35
White




H 37
White




H 38
White




H 39
White



H 40
White




H 41
Black




H 42
Black




H 43
White




H 44
White




H 45
White




H 46
White




H 47
Black



H 48
Black




H 49
Black



Position of Parts in Instrument Panel


H 50
Black




H 51
White



H 52
Black




H 53
White



H 54
Black



H 55
White



H 56
Yellow

