


Position of Parts in Instrument Panel



- A 13 Stop Lamp SW
- A 16 Clutch Start SW
- A 17 PTC Heater
- A 19 Power Steering ECU
- A 20 Accelerator Position Sensor
- A 26 Junction Connector
  
- E 1 Blower SW
- E 2 A/C Thermistor No.1
- E 3 Blower Resistor
- E 4 Blower Motor
- E 5 A/C SW
- E 6 Rear Window Defogger SW
- E 8 A/C Amplifier
- E 9 A/C Amplifier
- E 10 Junction Connector
  
- J 8 Airbag Sensor Assembly Center
- J 9 Airbag Sensor Assembly Center
  
- Q 1 Airbag Squib (Front Passenger's Airbag Assembly)
- Q 2 Airbag Squib (Front Passenger's Airbag Assembly)
  
- V 1 Steering Pad SW , Spiral Cable
  
- W 1 Airbag Squib (Steering Wheel Pad) , Spiral Cable
- W 2 Airbag Squib (Steering Wheel Pad) , Spiral Cable
  
- b 1 Power Steering Motor , Power Steering ECU
  
- c 1 Power Steering Torque Sensor , Power Steering ECU

# Position of Parts in Instrument Panel

