























Position of Parts in Instrument Panel



















- D 1 Combination Meter
- D 2 Combination Meter
- D 3 Spiral Cable
- D 4 Headlamp Dimmer SW Assembly
- D 5 Windshield Wiper SW Assembly
- D 6 Windshield Wiper SW Assembly
- D 7 Hazard Warning Signal SW
- D 8 Ignition SW
- D 9 Running Light Relay
- D 10 Radio Receiver Assembly
- D 11 Radio Receiver Assembly
- D 12 Outer Mirror SW
- D 13 Key Interlock Solenoid
- D 14 Cigarette Lighter or Power Outlet
- D 15 Data Link Connector 3
- D 16 Airbag Sensor Assembly Center
- D 18 Spiral Cable
- D 19 Unlock Warning SW
- D 20 A/T Shift Lever Illumination
- D 21 Parking Brake SW
- D 22 Shift Lock Control ECU
- D 23 Transponder Key ECU
- D 24 Transponder Key Amplifier
- D 25 Security Indicator Lamp
- D 26 Theft Warning ECU
- D 27 Passenger Seat Belt Warning Lamp
- D 28 Oxygen Sensor (Bank 1 Sensor 2)
- D 29 Light Control Rheostat
- D 30 Door Lock Control SW
- D 31 Power Steering ECU
- D 32 Antenna Amplifier
- D 33 Main Body ECU
- D 34 Junction Connector
- D 35 Junction Connector
- D 36 Junction Connector
- D 37 Junction Connector
- D 38 Junction Connector
- D 39 Junction Connector
- D 40 Junction Connector
- D 41 Junction Connector
- D 42 Junction Connector
- D 43 Fuse Block
- D 44 Diode (Starter)
- D 45 ACC Cut Relay
- D 46 Front Fog Light Relay
- D 74 Radio Receiver Assembly
- D 75 Stereo Jack Adapter

Position of Parts in Instrument Panel



Position of Parts in Instrument Panel




Position of Parts in Instrument Panel


D 44
Black




D 45
Gray



D 46
White



D 74
White



D 75
Gray

