


G ELECTRICAL WIRING ROUTING

Position of Parts in Instrument Panel

[LHD]



* 1:Automatic A/C
* 2:Except *1

- | | |
|---|---------------------------------------|
| A 11 A/C Amplifier | B 4 Blower Motor |
| A 12 A/C Control Assembly | B 5 Blower Motor Control |
| A 13 A/C Control Assembly | B 6 Blower Resistor |
| A 14 A/C Room Temp. Sensor | B 7 Blower SW |
| A 15 A/C Solar Sensor | B 8 Body ECU |
| A 16 A/C SW | |
| A 17 A/C Thermistor No.1 | C 8 Cigarette Lighter |
| A 18 Accelerator Position Sensor | C 9 Cigarette Lighter Illumination |
| A 19 Air Inlet Control SW | C 10 Circuit Opening Relay |
| A 20 Airbag Cut Off SW | C 11 Clearance Warning Buzzer |
| A 21 Airbag Sensor Assembly Center | C 12 Clearance Warning ECU |
| A 22 Airbag Sensor Assembly Center | C 13 Clutch Start SW |
| A 23 Airbag Sensor Assembly Center | C 14 Combination Meter |
| A 24 Airbag Squib (Front Passenger's Airbag Assembly) | C 15 Combination SW |
| A 25 Airbag Squib (Front Passenger's Airbag Assembly) | C 16 Combination SW |
| A 26 Airbag Squib (Steering Wheel Pad) | C 17 Cornering Assist Monitor Main SW |
| A 27 Antenna Amplifier | C 18 Cruise Control Clutch SW |