


G ELECTRICAL WIRING ROUTING

Position of Parts in Instrument Panel

[RHD]



* 1:Automatic A/C
* 2:Except *1

A 11 A/C Amplifier
A 12 A/C Control Assembly
A 13 A/C Control Assembly
A 14 A/C Room Temp. Sensor
A 15 A/C Solar Sensor
A 16 A/C SW
A 17 A/C Thermistor No.1
A 18 Accelerator Position Sensor
A 19 Air Inlet Control SW
A 20 Airbag Cut Off SW
A 21 Airbag Sensor Assembly Center
A 22 Airbag Sensor Assembly Center
A 23 Airbag Sensor Assembly Center
A 24 Airbag Squib (Front Passenger's Airbag Assembly)
A 25 Airbag Squib (Front Passenger's Airbag Assembly)
A 26 Airbag Squib (Steering Wheel Pad)
A 27 Antenna Amplifier

B 4 Blower Motor
B 5 Blower Motor Control
B 6 Blower Resistor
B 7 Blower SW
B 8 Body ECU
C 8 Cigarette Lighter
C 9 Cigarette Lighter Illumination
C 10 Circuit Opening Relay
C 11 Clearance Warning Buzzer
C 12 Clearance Warning ECU
C 13 Clutch Start SW
C 14 Combination Meter
C 15 Combination SW
C 16 Combination SW
C 17 Cornering Assist Monitor Main SW
C 18 Cruise Control Clutch SW