


Position of Parts in Instrument Panel

[RHD]



R 5 Radio Receiver Assembly
 R 6 Radio Receiver Assembly
 R 7 Radio Receiver Assembly
 R 8 Radio Receiver Assembly
 R 9 Radio Receiver Assembly
 R10 Rear Window Defogger Relay
 R11 Rear Window Defogger SW

S12 Shift Lever Position Sensor
 S13 Spiral Cable
 S14 Steering Lock Actuator
 S15 Steering Sensor (Back Guide Monitor)
 S16 Steering Sensor (VSC)
 S17 Stop Lamp SW

T 11 Television Camera Controller
 T 12 Television Camera Controller
 T 13 Temp. Control SW (Max Hot)
 T 14 Traction Control SW
 T 15 Transmission Shift Main SW
 T 16 Transponder Key ECU
 T 17 Turn Signal Flasher
 T 18 Tweeter (LH)
 T 19 Tweeter (RH)

V 3 VSC Warning Buzzer

W 5 Windshield Wiper Relay

Y 1 Yaw Rate Sensor

Z 2 Option Connector (TVSS ECU)