


## Connector Joining Wire Harness and Wire Harness



Code	Joining Wire Harness and Wire Harness (Connector Location)
IF1	Instrument Panel Wire and Switch Wire (Instrument Panel Brace LH)
IG1	Instrument Panel Wire and A/C No.1 Wire (Behind the Combination Meter)
IH1	Instrument Panel Wire and Instrument Panel No.3 Wire (Near the Front Passenger's Airbag Assembly)
II1	Instrument Panel Wire and A/C No.1 Wire (Near the A/C Unit)
IJ1	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
IJ2	
IK1	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IK2	
IL1	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
IL2	
IM1	Floor No.2 Wire and Instrument Panel Wire (Right Kick Panel)
IN1	Instrument Panel Wire and A/C No.1 Wire (Near the A/C Unit)