

Service Hints

FR FOG Relay

5-3 : Closed with the light control SW at TAIL or HEAD position and the fog light SW at FRONT or REAR (w/ front fog light) position

○ : Parts Location

Code	See Page	Code	See Page	Code		See Page
C14	44 (LHD)	F1	50 (*3)	J5	A	45 (LHD)
	54 (RHD)		52 (*4)			55 (RHD)
C15	44 (LHD)	F2	40 (*1)	J6	B	45 (LHD)
	54 (RHD)		42 (*2)			55 (RHD)
F1	40 (*1)		50 (*3)	J19		45 (LHD)
	42 (*2)		52 (*4)			55 (RHD)

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
3	26	Engine Room R/B No.3 (Left Side of the Suspension Tower)
8	31	R/B No.8 (Instrument Panel Center)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
4B	27	Engine Room Main Wire and Engine Room J/B No.4 (Left Side of the Suspension Tower)
4D		
CA	36 (LHD)	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
	36 (RHD)	Instrument Panel Wire and Center J/B (Instrument Panel Reinforcement RH)
CF	36 (LHD)	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
	36 (RHD)	Instrument Panel Wire and Center J/B (Instrument Panel Reinforcement RH)
CJ	37 (LHD)	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
	37 (RHD)	Instrument Panel Wire and Center J/B (Instrument Panel Reinforcement RH)
DA	32	Instrument Panel Wire and Instrument Panel J/B (Left Side of the Instrument Panel)
DB		
DJ		
DN	33	Engine Room Main Wire and Instrument Panel J/B (Left Side of the Instrument Panel)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EE1	62 (*2)	Engine Wire and Engine Room Main Wire (Left Side of the Suspension Tower)
	72 (*4)	

▽ : Ground Points

Code	See Page	Ground Points Location
EB	60 (*1)	Engine Compartment Right
	62 (*2)	
	70 (*3)	
	72 (*4)	
ED	60 (*1)	Engine Compartment Left
	62 (*2)	
	70 (*3)	
	72 (*4)	
IJ	64 (LHD)	Behind the Combination Meter
	74 (RHD)	
IM	64 (LHD)	Right Kick Panel
	74 (RHD)	

* 1 : LHD 1ZZ-FE, 3ZZ-FE * 2 : LHD 1CD-FTV * 3 : RHD 1ZZ-FE, 3ZZ-FE * 4 : RHD 1CD-FTV * 5 : 1ZZ-FE, 3ZZ-FE * 6 : 1CD-FTV