



- G 1 Speaker (Front Door RH)
- G 2 Power Window Regulator Motor (Front RH)
- G 3 Power Window SW (Front Passenger's Side)
- G 4 Outer Rear View Mirror (RH)
- G 5 Door Lock Assembly (Front RH)
- G 7 Tweeter (Front RH)

- H 1 Speaker (Front Door LH)
- H 2 Power Window SW (Driver's Side)
- H 3 Outer Rear View Mirror (LH)
- H 4 Power Window Regulator Motor (Front LH)
- H 5 Door Lock Assembly (Front LH)
- H 6 Tweeter (Front LH)

- I 1 Power Window SW (Rear RH)
- I 2 Speaker (Rear RH)
- I 3 Power Window Regulator Motor (Rear RH)
- I 4 Door Lock Assembly (Rear RH)

- J 1 Power Window SW (Rear LH)
- J 2 Speaker (Rear LH)
- J 3 Power Window Regulator Motor (Rear LH)
- J 4 Door Lock Assembly (Rear LH)

- Y 1 Door Outside Handle (Front RH)
- Y 2 Electrical Key Oscillator (Front Door RH)

- Z 1 Door Outside Handle (Front LH)
- Z 2 Electrical Key Oscillator (Front Door LH)

Position of Parts in Body <LHD Short Body>

