| | | |
|---|---|---|
| **Last Modified:** 03-12-2013 | 6.4 F | **Doc ID:** NM1000000005Q6R |
| **Model Year:** 2013 | **Model:** RAV4 | **Prod Date Range:** [12/2012 - ] |
| **Title:** U760F AUTOMATIC TRANSMISSION / TRANSAXLE: AUTOMATIC TRANSAXLE SYSTEM: OIL PUMP; 2013 MY RAV4 [12/2012 - ] | | |

# OIL PUMP

## 1. CONSTRUCTION

(a) The oil pump is operated by the torque converter. The oil pump lubricates the planetary gear units and supplies operating fluid pressure for hydraulic control.

(b) The pump cover is made of aluminum to reduce weight.




| | | | |
|---|---|---|---|
| *1 | Pump Body | *2 | Drive Gear |
| *3 | Driven Gear | *4 | Stator Shaft |
| *5 | Pump Cover | - | - |