| | | |
|---|---|---|
| **Last Modified:** 03-12-2013 | 6.4 F | **Doc ID:** NM1000000005IHS |
| **Model Year:** 2013 | **Model:** RAV4 | **Prod Date Range:** [12/2012 - ] |
| **Title:** LIGHTING (EXT): LIGHTING SYSTEM: LIGHT AUTO TURN-OFF CONTROL; 2013 MY RAV4 [12/2012 - ] | | |

# LIGHT AUTO TURN-OFF CONTROL

### 1. SYSTEM CONTROL

(a) The light auto turn-off system operates as follows:

| CONDITION | DETAILS |
|---|---|
| Delay | When approx. 30 seconds elapse after all of the following conditions are met, the exterior lights turn off:<br>• The ignition switch is turned off.<br>• All doors are closed.<br>• The light control switch (headlight dimmer switch assembly) is in the AUTO position. |