| | | |
|---|---|---|
| **Last Modified:** 03-12-2013 | 6.4 F | **Doc ID:** NM1000000004IE0 |
| **Model Year:** 2013 | **Model:** RAV4 | **Prod Date Range:** [12/2012 - ] |
| **Title:** PARK ASSIST / MONITORING: INTUITIVE PARKING ASSIST SYSTEM: CLEARANCE WARNING ECU; 2013 MY RAV4 [12/2012 - ] | | |

# CLEARANCE WARNING ECU

## 1. CONSTRUCTION

(a) The clearance warning ECU assembly performs overall control of the system, including switching between transmission and reception of the ultrasonic sensor signals, processing the received wave signals, determining the presence of obstacles, actuating the No. 1 clearance warning buzzer and determining the presence of an open circuit in the sensors.