| | | |
|---|---|---|
| **Last Modified:** 03-12-2013 | 6.4 F | **Doc ID:** NM1000000004IDL |
| **Model Year:** 2013 | **Model:** RAV4 | **Prod Date Range:** [12/2012 - ] |
| **Title:** AUDIO / VIDEO: AUDIO AND VISUAL SYSTEM: AUDIO CONTROL; 2013 MY RAV4 [12/2012 - ] | | |

# AUDIO CONTROL

## 1. FUNCTION OF MAIN COMPONENTS

| COMPONENT | FUNCTION |
|---|---|
| Audio Head Unit | Receives each type of signal and outputs the signals to each component. |
| Telephone Microphone Assembly | Transmits the voice input signals to the audio head unit. |
| Steering Pad Switch Assembly | Transmits the operation signals from the switches to the audio head unit. |
| No. 1 Stereo Jack Adapter Assembly | Transmits information about the portable audio player (USB type) connected to the USB port or AUX port to the audio head unit. |
| Combination Meter Assembly | Transmits received vehicle speed signals to the audio head unit. |