| | | |
|---|---|---|
| **Last Modified:** 03-12-2013 | 6.4 F | **Doc ID:** NM1000000005PUO |
| **Model Year:** 2013 | **Model:** RAV4 | **Prod Date Range:** [12/2012 - ] |
| **Title:** BRAKE CONTROL / DYNAMIC CONTROL SYSTEMS: BRAKE CONTROL SYSTEM: SYSTEM DIAGRAM; 2013 MY RAV4 [12/2012 - ] | | |

# SYSTEM DIAGRAM


Front Speed Sensor RH
Front Speed Sensor LH
Rear Speed Sensor RH
Rear Speed Sensor LH
VSC OFF Switch
(Traction Control Switch)
Stop Light Switch Assembly
Stop Light Control Relay
Assembly
Stop Light
Master Cylinder
Pressure Sensor
Motor Cut Relay
Motor Relay
Pump Motor
Master Cylinder Solenoid
Valves
Solenoid Relay
Solenoid Valves
Skid Control ECU
Brake Actuator Assembly
DLC3
Combination Meter Assembly
Speedometer
Buzzer
Main Body ECU
(Multiplex Network Body
ECU)
CAN (V Bus)
Parking Brake Switch Assembly




*1: AWD models

*2: 2WD models