| | | |
|---|---|---|
| **Last Modified:** 03-12-2013 | 6.4 F | **Doc ID:** NM1000000004IDM |
| **Model Year:** 2013 | **Model:** RAV4 | **Prod Date Range:** [12/2012 - ] |
| **Title:** AUDIO / VIDEO: AUDIO AND VISUAL SYSTEM: BLUETOOTH AUDIO CONTROL; 2013 MY RAV4 [12/2012 - ] | | |

# BLUETOOTH AUDIO CONTROL

## 1. FUNCTION

(a) The functions of the Bluetooth audio system that can be used vary with the version of the Audio/Video Remote Control Profile (AVRCP) supported by the Bluetooth audio player that is being used.

(b) The available Bluetooth audio system functions differ in accordance with each Audio/Video Remote Control Profile (AVRCP) as follows:

| FUNCTION | OUTLINE | AUDIO/VIDEO REMOTE CONTROL PROFILE (AVRCP) | | |
|---|---|---|---|---|
| | | VERSION 1.0 | VERSION 1.3 | VERSION 1.4 OR HIGHER |
| Play | Starts playing the music. | ○ | ○ | ○ |
| Stop | Stops playing the music. | ○ | ○ | ○ |
| Pause | Pauses the music. | ○ | ○ | ○ |
| Track Up/Down | Changes the track. | ○ | ○ | ○ |
| Fast Up/Down | Fast-forwards or reverses. | ○ | ○ | ○ |
| Album Up/Down | Changes the album. | - | ○ | ○ |
| Repeat (Single Repeat) | Repeats the selected music. | - | ○ | ○ |
| Random (All Track Random) | Plays all the music in the portable audio device at random. | - | ○ | ○ |
| Scan (All Track Scan) | Scans all the music in the portable audio device. | - | ○ | ○ |
| Music Information | Shows the track number, playtime, track name artist name and album name. | - | ○ | ○ |
| Remaining Battery Level | Shows the remaining battery level of the Bluetooth audio player. | - | ○ | ○ |
| Music List | Shows the music list. | - | - | ○ |

**HINT:**

○ : Usable

- : Not Usable

(c) The functions of the Bluetooth audio system are shown in the following table:

| FUNCTION | | OUTLINE |
|---|---|---|
| Set Bluetooth Audio Player | Registering a Bluetooth Audio Player | In order to use the Bluetooth audio system with a Bluetooth audio player, it is necessary to register the audio player in the audio head unit. Once a Bluetooth audio player is registered, the Bluetooth audio system becomes available automatically. |
| | Deleting a Bluetooth Audio Player | The user can delete a Bluetooth audio player. |
| | Connecting a Bluetooth Audio Player | The user can select whether to connect to the Bluetooth audio player automatically or manually. If the Bluetooth audio player has been registered and automatic connection is enabled, the Bluetooth audio player will be connected automatically. |
| Change Settings of Bluetooth Audio | Selecting a Bluetooth Audio Player | If the user has registered a second Bluetooth audio player, either one can be selected for connection. |
| | Displaying the Bluetooth Audio Player | The user can view the information of the Bluetooth audio player on the system. |
| | Changing the Connection Method | The user can select the connection method. With this function, the user determines whether to make a connection from the audio head unit to the Bluetooth audio player or from the Bluetooth audio player to the audio head unit. |
| | Displaying the Bluetooth Audio Settings | The user can see the Bluetooth audio information settings on the system. |
| | Changing the Device Name or Passcode | The user can change a device name or a passcode. |
| | Initializing the Bluetooth Audio Settings | The user can initialize the settings. |