| | | |
|---|---|---|
| **Last Modified:** 03-12-2013 | 6.4 F | **Doc ID:** NM1000000005IIN |
| **Model Year:** 2013 | **Model:** RAV4 | **Prod Date Range:** [12/2012 - ] |
| **Title:** HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: SYSTEM DIAGRAM; 2013 MY RAV4 [12/2012 - ] | | |

# SYSTEM DIAGRAM

w/ Manual Air Conditioning System:

w/ Manual Air Conditioning System:




*: 2WD Models

w/ Automatic Air Conditioning System:


Blower Motor with Fan Sub-assembly
- Blower Motor Controller
Cooler (Room Temp. Sensor) Thermistor
No. 1 Cooler Thermistor
Air Conditioning Pressure Sensor
Solar Sensor (Automatic Light Control Sensor)
Eco Mode Switch
ECM
Combination Meter Assembly
CAN (V Bus)
Air Conditioning Control Assembly
LIN
Air Conditioning Amplifier Assembly
PTC Heater Relay
PTC Heater (Quick Heater Assembly)
Rear Window Deffoger Relay
Compressor with Pulley Assembly
- Solenoid
- Magnet Clutch Assembly*
No. 1 Air Conditioning Radiator Damper Servo Sub-assembly
No. 2 Air Conditioning Radiator Damper Servo Sub-assembly
No. 3 Air Conditioning Radiator Damper Servo Sub-assembly
No. 1 Blower Damper Servo Sub-assembly
*: 2WD Models