| | | |
|---|---|---|
| **Last Modified:** 03-12-2013 | 6.4 F | **Doc ID:** NM1000000004IHF |
| **Model Year:** 2013 | **Model:** RAV4 | **Prod Date Range:** [12/2012 - ] |
| **Title:** SEAT: POWER SEAT CONTROL SYSTEM: GENERAL; 2013 MY RAV4 [12/2012 - ] | | |

# GENERAL

## 1. OUTLINE

(a) Front Power Seat Control System

(1) A front power seat control system is provided for the driver seat.

(2) A memory function is used in the power seat control system for the driver seat.

## 2. SPECIFICATION

(a) The power seat control system for the driver seat has the following functions:




| ADJUSTMENT FUNCTION | | STROKE |
|---|---|---|
| NO. | ITEM | |
| (1) | Seat Slide | 240 mm (9.4 in.) |
| (2) | Seat Reclining | 52 degrees |
| (3) | Front Vertical | 34.2 mm (1.3 in.) |
| | | |

| | | |
|---|---|---|
| (4) | Seat Lifter | 56.7 mm (2.2 in.) |
| (5) | Lumbar Support | 30 mm (1.2 in.) |

## 3. PRECAUTION

(a) Ignition Switch Expressions

(1) The type of ignition switch used on this model differs depending on the specifications of the vehicle. The expressions listed in the table below are used in this section.

| EXPRESSION | IGNITION SWITCH (POSITION) | ENGINE SWITCH (CONDITION) |
|---|---|---|
| Ignition Switch off | LOCK | Off (Lock) |
| Ignition Switch ACC | ACC | On (ACC) |
| Ignition Switch ON | ON | On (IG) |
| Engine Start | START | On(Start) |