14 SEQUOIA

(Cont. next page)




Multi Mode 4WD
5
6
7
8
F1
Differential Vacuum Actuator Assembly
M
ADD
DM1
DM2
DL2
DL1
GND
DF1
DA1
A28(A), A29(B)
Four Wheel Drive Control ECU
W–B
(*2)
(*1)
B
D3
(BAT)
(IG)
5A
MET–B
7. 5A
MET
AH9
H37
Combination Meter Assembly
Power Circuit
4HI
4LO
Center Differential Lock
+B
IG
Buzzer
CANH
CANL
E1
Multiplex Communication
System (CAN)<2–6>
H85
Junction Connector
H1
H2
* 1 : 3UR–FE
* 2 : 2UZ–FE