
Audio System (Built–in Type Amplifier)
1
2
3
4
(BAT)
15A
RAD
NO. 1
(ACC)
7. 5A
ACC
N7
Rear Door
Speaker LH
N1
Rear Door
Speaker RH
O31
Quarter Side Speaker
Assembly LH
O37
Quarter Side Speaker
Assembly RH
H7
No. 1 Stereo Jack Adapter Assembly
ALO
ARO
ASGN
AUXG
AUXO
(Shielded)
Antenna
I23
Amplifier Antenna
Assembly
B
ACC
RL+
RL–
RR+
RR–
ALI
ARI
ASGN
AUXG
AUXI
ANT
I1(A), I2(B), I3(C)
Radio Receiver Assembly
GND
FL+
FL–
FR+
FR–
SPD
TWL+
TWL–
TWR+
TWR–
I13
Front Side Speaker LH
I11
Front Side Speaker RH
Combination Meter Assembly
<38–1>
M10
Front Door Speaker LH
L8
Front Door Speaker RH