

ABS WITH EBD & BA & TRC & VSC SYSTEM

05K15-01

PRECAUTION

- When there is a malfunction in the contact point of the terminals or installation problems with parts, removal and installation of the suspected problem parts may return the system to the normal condition either completely or temporarily.
- In order to determine the malfunctioning area, be sure to check the conditions at the time the malfunction occurred, such as by DTC output and the freeze frame data output, and record it before disconnecting each connector or removing and installing parts.
- Since the ABS with EBD & BA & TRC & VSC systems may be influenced by a malfunction in the other systems, be sure to check for DTCs in the other systems.
- Be sure to remove and install the skid control ECU with actuator and each sensor with the IG switch off unless specified in the inspection procedure.
- When removing and installing the skid control ECU with actuator and each sensor, be sure to check that the normal display is output in test mode inspection and in DTC output inspection after installing all the parts.
- After replacing the yaw rate sensor and/or the ABS & TRC actuator, make sure to perform yaw rate sensor and deceleration sensor zero point calibration. (See page 05-610)
- CAN communication system is used for the data communication between the skid control ECU (included in the actuator), the steering angle sensor, and the yaw rate sensor (the deceleration sensor is included). If there is a problem in the CAN communication line, the DTC in the communication line is output.
- If the DTC in the CAN communication line is output, repair the malfunction in the communication line and troubleshoot the ABS with EBD & BA & TRC & VSC systems.
- Since the CAN communication line is a dedicated line, it can not be repaired temporarily with the bypass wire, etc.