

# TROUBLESHOOTING

## PROBLEM SYMPTOMS TABLE

BR07J-08

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

| Symptom   | Suspect Area   | See page  |
|---|--|---|
| Low pedal or spongy pedal   | 4. Brake system (Fluid leaks)<br>5. Brake system (Air in)<br>6. Piston seals (Worn or damaged)<br>7. Rear brake shoe clearance (Out of adjustment)<br>8. Hydraulic brake booster (Faulty)  | <a href="#">DI-374</a><br><a href="#">BR-4</a><br><a href="#">BR-15</a><br><a href="#">BR-25</a><br><a href="#">BR-26</a>   |
| Brake drag  | 1. Brake pedal freeplay (Minimal)<br>2. Parking brake lever travel (Out of adjustment)<br>3. Parking brake wire (Sticking)<br>4. Rear brake shoe clearance (Out of adjustment)<br>5. Pad or lining (Cracked or distorted)<br>6. Piston (Stuck)<br>7. Piston (Frozen)<br>8. Anchor or return spring (Faulty)<br>9. Hydraulic brake booster (Faulty) | <a href="#">BR-9</a><br><a href="#">BR-11</a><br>-<br><a href="#">BR-25</a><br><a href="#">BR-12</a><br><a href="#">BR-21</a><br><a href="#">BR-15</a><br><a href="#">BR-15</a><br><a href="#">BR-21</a><br><a href="#">BR-26</a>   |
| Brake pull  | 1. Piston (Stuck)<br>2. Pad or lining (Oily)<br>3. Piston (Frozen)<br>4. Disc (Scored)<br>5. Pad or lining (Cracked or distorted)<br>6. Hydraulic brake booster (Faulty)   | <a href="#">BR-15</a><br><a href="#">BR-12</a><br><a href="#">BR-21</a><br><a href="#">BR-15</a><br><a href="#">BR-15</a><br><a href="#">BR-12</a><br><a href="#">BR-21</a><br><a href="#">BR-26</a>  |
| Hard pedal but brake inefficient  | 1. Brake system (Fluid leaks)<br>2. Brake system (Air in)<br>3. Pad or lining (Worn)<br>4. Pad or lining (Cracked or distorted)<br>5. Rear brake shoe clearance (Out of adjustment)<br>6. Pad or lining (Oily)<br>7. Pad or lining (Glazed)<br>8. Disc (Scored)<br>9. Hydraulic brake booster (Faulty)   | <a href="#">DI-374</a><br><a href="#">BR-4</a><br><a href="#">BR-12</a><br><a href="#">BR-21</a><br><a href="#">BR-12</a><br><a href="#">BR-21</a><br><a href="#">BR-25</a><br><a href="#">BR-12</a><br><a href="#">BR-21</a><br><a href="#">BR-12</a><br><a href="#">BR-21</a><br><a href="#">BR-15</a><br><a href="#">BR-26</a> |
| Noise from brakes   | 1. Pad or lining (Cracked or distorted)<br>2. Installation bolt (Loose)<br>3. Disc (Scored)<br>4. Pad support plate (Loose)<br>5. Sliding pin (Worn)<br>6. Pad or lining (Dirty)<br>7. Pad or lining (Glazed)<br>8. Anchor or return spring (Faulty)<br>9. Anti-squeal shim (Damaged)<br>10. Shoe hold-down spring (Damaged)                       | <a href="#">BR-12</a><br><a href="#">BR-21</a><br><a href="#">BR-15</a><br><a href="#">BR-12</a><br><a href="#">BR-15</a><br><a href="#">BR-12</a><br><a href="#">BR-21</a><br><a href="#">BR-12</a><br><a href="#">BR-21</a><br><a href="#">BR-12</a><br><a href="#">BR-21</a><br><a href="#">BR-12</a><br><a href="#">BR-21</a> |
| Noise from hydraulic brake booster<br>(Abnormal pump motor operation noise) | Accumulator bracket clearance (Out of adjustment)  | <a href="#">BR-44</a>   |

## BRAKE - TROUBLESHOOTING

|   |   |                            |
|---|---|----------------------------|
| Brake warning light lights up* <sup>1</sup><br>(Parking brake lever released) | 1. Brake fluid level<br>2. Hydraulic brake booster power supply system (Faulty)                 | -<br><a href="#">BR-26</a> |
| Brake warning light lights up and brake warning buzzer sounds* <sup>2</sup>   | Hydraulic brake booster power supply system (Faulty)  | <a href="#">BR-26</a>      |
| ABS warning light lights up* <sup>3</sup>                                     | 1. Anti - lock brake system (Faulty)<br>2. Hydraulic brake booster power supply system (Faulty) | -<br><a href="#">BR-26</a> |

\*<sup>1</sup>, \*<sup>3</sup>: The light may stay on for about 60 seconds after the engine is started. It is normal if it goes out after a while.

\*<sup>2</sup>, \*<sup>3</sup>: Depressing the brake pedal repeatedly may turn on the warning light and buzzer. It is normal if the light goes off and the buzzer stops sounding after a few seconds.

\*<sup>3</sup>: While ABS warning light is ON.